

VSM₄₂₂

VESSEL SYSTEMS MONITOR



4 METERS IN 1

1. DC Systems Monitor

voltage (up to 3 batteries), amperage, battery state of charge—amp hours remaining, time remaining, % charge, battery temperature, cycle count

- AC Systems Monitor voltage, amperage, watts, frequency
- 3. Tank Monitor (up to 3 tanks) gasoline, diesel, water, waste
- Bilge Monitor bilge pump—active, cycle count, duration/hr, cycle/24 hr

Alarms—high and low

DC-alarms for all values

AC-alarms for voltage, amperage, and frequency Tank-high and low level alarms for fuel, water and waste

Bilge—alarms for cycles, duration/hr

Display-three intuitive modes

- · multi-line text to monitor all systems at a glance
- · icons for simple visual status
- · large font that can be read from a distance
- Mounting—versatile case design offers three mounting options
- Customization—programmable legends and adjustable alarm functions

BLUE SEA SYSTEMS ULTRASONIC TANK SENDERS AVAILABLE





VSM 422 PANEL MOUNTING OPTIONS

PN 1325 360 Panel Mounting Kit



PN 1519 360 Panel Blank



Replace these 4 meters with the VSM 422








Part Number

1800

Vessel Systems Monitor





VSM 422

VESSEL SYSTEMS MONITOR

Specifications


DC	
Nominal System Voltage	12 or 24V
Operating Voltage	8.5-33.0V
Minimum Current Draw	35mA @ 12V, backlight off
	18.8mA @ 24V, backlight off
Voltage Accuracy	+/- 0.5%
Current Range	0-500A
Current Accuracy	+/- 1.0%

AC

Nominal System Voltage	120V @ 60Hz, North America
	230V @ 50Hz, Typical of Europe
Operating Voltage	0-300V
Voltage Accuracy (RMS)	+/- 0.5%
Current Range	0-150A
Current Accuracy (RMS)	+/- 2.0%
Frequency	40-90Hz
Regulatory	

C € Marked for E60945 electromagnetic interference

67 IP67—protected against immersion up to 1 meter for 30 minutes VSM 422 Surface Mount Gasket creates a waterproof seal on unit face.



Tank Senders Supported:

10 – 180 Ω VDO—Typical of Europe


240 – 33 Ω Teleflex—North America

Blue Sea Systems Ultrasonic Tank Senders (sold separately)

- for diesel, water, or waste PN 1810 (32" tank depth)
- · for gasoline PN 1811 (24" tank depth)

Specifications subject to change.
See www.bluesea.com for additional information and specifications.

VESSEL SYSTEMS MONITOR



Select one optional input


Battery 3

OR

Tank 3 Level

OR

Bilge Switch



Included in Retail Packaging: head unit, surface mount bezel, surface mount gasket, DC Current Shunt - PN 8255, AC Current Transformer - PN 8256, Battery Temperature Sensor - PN 1820, connectors and mounting screws





425 Sequoia Drive Bellingham, WA 98226 USA p 360.738.8230

p 800.222.7617 USA and Canada Customer Service f 360.734.4195

conductor@bluesea.com www.bluesea.com